



## DRIVER INSTALLATION INSTRUCTIONS

RAZER BLADE STEALTH 13 (2019) INTEL THUNDERBOLT 3 DRIVER  
VERSION 1.41.484.0

---

## DRIVER INSTALLATION INSTRUCTIONS

### APPLICABLE MODEL NUMBERS

- RZ09-02812
- RZ09-02810

### DRIVER NAME AND VERSION

Intel Thunderbolt 3 Driver version 1.41.484.0

### INSTRUCTIONS

**Note:** This download is for the original driver that was installed on your Razer Blade Laptop. Updates for this driver are available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.

- Ensure your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
- Please save any open documents on your computer and close all other programs before attempting this update
- Download the driver from the link below. You will need to right click the .zip folder and choose to extract the files to a location of your choosing (such as your desktop) to locate the files for the installation process.


<http://rZR.to/Zpqh0>

- Once you have extracted the file proceed to the installation steps below.


---

## INSTALLATION PROCESS

1. To initiate the installation process of this Thunderbolt™ 3 driver, click on the Driver-Service setup.bat (Windows Batch File) as shown in the image below:



2. Upon clicking the Driver-Service setup.bat (Windows Batch File), a Windows Terminal Shell window will appear with the message that it is installing the Thunderbolt driver. After a few moments, the window will display the message 'Press any key to continue . . .'. Press any key as it instructs, and the install of this driver will be complete.



3. End